

Entkalken • Decalcificare



Anzeige Entkalken Indicazione Decalcificare



1 Düse Beccuccio



Düse abschrauben
Svitare il beccuccio

Zerlegen + reinigen
Smontare e pulire

2 Vorbereiten Preparazione

Gerät ~~AUS~~ EIN
Apparecchio spento



Kapsel auswerfen
Espellere la capsula



Abtropfschale leeren
Svuotare la vaschetta
raccogliogocce



0,1 l Entalker +
0,9 l Wasser
0,1 l decalcificante +
0,9 l di acqua



Gefäß unterstellen
Mettere sotto una
tazzina

3 Entkalken Decalcificare

Nie Essig verwenden
Non usare mai aceto



60 Sekunden
60 secondi



3 Zyklen
3 cicli



Heisswasser EIN
Acqua calda ON



2 Zyklen
2 cicli

4 Spülen Risciacquo



Abtropfschale
leeren. Tank spülen
+ ganz füllen
Svuotare vaschetta.
Sciquare e
riempire il serbatoio



2 Zyklen
2 cicli




Heisswasser AUS
Acqua calda OFF



2 Zyklen
2 cicli

5 Beenden Terminare

Düse
zusammensetzen +
anschrauben
Fissare il beccuccio
e avvitarlo



Warten bis Maschine selbst ausschaltet.
Entkalkung fertig.
Aspettare che la macchina si spenga da sola.
L'eliminazione del calcare è terminata.